# Android HDMI Stick MANUAL V0.1



## Index

#### Prepare

1.Connect TV

2. Connect mouse, Power On

3. Connect the power

#### Use it

Connect the network

5.Adjust display resolution

6. Adjust volume

7. Copy files

8.Install/Uninstall Application (apk)

\*\*\*\*\*

# repare

connect to TV

Connect the Android HDMI stick to TV through HDMI interface; Or use the HDMI cable connect he Android HDMI stick and TV

Power on the TV, use the TV remote controller o switch the 'Video source' to HDMI. (Please efer to TV's user manual for reference)

Connect USB mouse

The USB mouse to control the Android HDMI stick, it is the same way with use it on PC. It can ise an ordinary mouse, or 2.4G wireless mouse. Vote:

Please notice, use a mouse to run an application or control the menu, it needs 'Single

Click', not 'Double Click'

#### Power on

Connect power

1. Supply the power to 'power adaptor', which is

2. Connect the USB cable to 'power adaptor' and Android HDMI stick

3. After the above 2 steps, Android HDMI stick powers on, the LED indicator will be On 4. Wait for the power on complete, the TV will display the below screen.



If cannot power on normally, please refer to FAQ

#### Use it

Connect to the network.

Android HDMI stick builds in Wi-Fi, it needs to setup the Wi-Fi network to let it work with a new Wi-FIAP.

1. User the mouse, click the 'Setup'



2.In the setup menu, 'Setup->Wi-Fi', Check 'Wi-Fi'. Select Wi-Fi AP name



3. Input the password (if needs), click 'Connect', wait for the Wi-Fi connection establish, when it has been done, a Wi-Fi icon appears in the bottom right corner of the screen.

Adjust the display resolution

If the TV display abnormal, please try to adjust the resolution, run 'Setup', enter the menu 'Display->Resolution', check 'Auto Detect'; and 'Display->Change Display Resize' to



### Adjust the volume

It can adjust the volume by clicking the icons in below picture.



#### Copy files (from/to PC)

1. Connect the Android HDMI stick with PC by USB cable. If the Android HDMI stick connect the TV at the same TV, please wait for the below screen appear. Don't shut out the cooling holes. 2. Use the mouse; click red cycle 1, then red cycle



3. Click the button in the red cycle (in below picture)



4. Wait for a new 'drive' appear in the PC

# Install/Uninstall the application Install:

1. Click the icon in the right top corner, it will display all the installed application.



2.Run 'Google Play' (or it can use 3rd party application market)



3.If it is the first time run 'Google play', please input the Google account according to the system guidance.

#### Uninstall:

Run 'Setup', please reference below picture, click red cycle 1, all the user installed application will be displayed in red rectangle 2, find the application you want to uninstall, click it, and follow the system guidance to uninstall it.



#### FAQ:

In the power cable (USB cable) already connected, but LED indicator is still OFF, please check the power adaptor; if use the TV's USB port to supply the power, please change to power adaptor.

2. If LED indicator is ON, but there is no HDMI output, please check if the HDMI cable connect properly, and check if the TV's video source has been switch to HDMI

3.If USB mouse has been connect to Android HDMI stick, but there is no mouse cursor, please check if the mouse connected properly, and if a battery needed for 2.4G wireless mouse. (There is very few kinds of mouse don't work with Android HDMI stick)

4.If the Wi-Fi network has been setup, but Android HDMI stick doesn't access the internet, please check if the Wi-Fi icon is gray color, which means the Wi-Fi signal is weak, please consider to adjust the Wi-Fi equipment or find your network technical support

5.If there is no 'Soft Keyboard' when click a place to input, please find the small 'keyboard' icon in the bottom right corner, and select the switch off the physical keyboard.

6. Some applications are designed for mobile phone, which has the difference resolution from Android HDMI stick's HDMI (1920x1080), they don't work full screen in TV.

7.If some application don't work on Android HDMI stick, they are not optimized on Android 4.0