


Quick Start **Guide**




ZUG 1



1 Release the battery cover

Turn both screws anti-clockwise to release battery door and lift off using the slot beneath the LED torch.

M card
honesty as
e down).



3 Insert Micro-SD card

Slide the metal clasp left and it will hinge up from the left. Place SD card into position, then close the metal clasp, and slide right to lock in place.

4 Replace battery cover

Position tabs on battery door in the phone first, and close it up. Whilst still applying pressure to the door beneath the screw heads, turn screws clockwise until resistance is felt, then add a quarter turn more. The door must be secured to ensure watertight seal. Take care not to over tighten.



5 Charge for 6 hours

Please charge for 6 hours before initial use.

Keypad Description

