Quick Start Guide



ZUG 5



Release the battery cover

Turn both screws anti-clockwise to release battery door and lift off using the slot beneath the LED torch.







3 Insert Micro-SD card

Slide the metal clasp right and it will hinge up from the right. Place SD card into position, then close the metal clasp, and slide left to lock in place.

Replace battery cover

Position tabs on battery door in the phone first, and close it up. Whilst still applying pressure to the battery door point A & B to make sure it can fit housing well, and then beneath the screw heads, turn screws clockwise until resistance is felt, then add a quarter turn more. The door must be secured to ensure watertight seal. Take care not to over tighten.



5 Charge for 6 hours

Please charge for 6 hours before initial use.



Keypad Description





