快速使用手册

ZUG 3





1 打开电池盖

逆时针旋转两个电池盖 螺丝后取出电池盖



2 插入SIM卡

如右图所示插入SIM卡1 (WCDMA 3G卡或GSM 2G卡) /SIM卡2 (GSM 2G卡), 也可只插入一张SIM卡



3插入Micro-SD卡

如左图所示,向上滑动 金属片打开Micro-SD崇槽, 插入Micro-SD盖上卡槽, 向下滑动金属片固定 Micro-SD



向上插入电池压平,然后把电池盖向下对准那两个卡口插入,压住上部顺时针旋转两个电池盖螺丝,直到固定整个电池盖



5充电6小时

初次使用时,请充电6小时



按键描述





Quick Start Guide




ZU6 3.



Release the battery cover

Turn both screws anti-clockwise to release battery door and lift off using the slot beneath the LED torch.



shown (contacts face down).



3 In 6lide will h SD c

Insert Micro-SD card

Glide the metal clasp left and it will hinge up from the left. Place SD card into position, then close the metal clasp, and slide right to lock in place.

4Replace battery cover

Position tabs on battery door in the phone first, and close it up. Whilst still applying pressure to the door beneath the screw heads, turn screws clockwise until resistance is felt, then add a quarter turn more. The door must be secured to ensure watertight seal. Take care not to over tighten.



Keypad Description





5 Charge for 6 hours

Please charge for 6 hours before initial use.

