

DOOGEE

VOYAGER2 DG310

Quick guide

Guide rapide

Guía rápida

Guida rapida

Guia rápida

www.doogee.cc



VOYAGER2 DG310

The contents of this manual may differ in certain respects from the description of your phone depending on its software version and your telephone operator.

Quick guide

EN


Getting to Know Your Phone




* please use the earphone attached to the package .

Use the phone keys

In any screen,

Tap “”, return to the former interface or exit.

Tap “”, return to the menu.

Tap “”, display the setting-options list.

Tap the “on / off” button, turn off or light up the screen; long press “on / off” button for a few seconds, you can choose to shut down or restart the phone.

Press and hold the “on / off” button and volume down key, the interception of the screen.

Language switching

Tap the “Settings” icon. so you can go into the field of “Language & input”, then you can choose the language on the field of “Language”.



Settings

Making Calls

Pressing the button of "People", email, message or any telephone number on the phone then you make a phone call. Or make a phone call by using the dial keyboard in the "Dialing" application program.



Phone

Message


Tap the "Messaging" icon, then you can send a **message** to other user,. Input names and telephone numbers on the "Receiver" field, or choose someone in the contact list, then press the "sending" button after inputting the message. Please press the "⊕" button if you want to send a photograph, video and so on.



Messaging


Input and edit

The DG310 will have some recommendation when you are inputting. If you want to edit a text, please choose the text and then press it for several seconds, move the inseting point or using the select all, cut and copy ways.




Record colorful moments


Tap the "Camera" icon to open the camera. DG310 support a variety of pictures of intelligent beauty, HDR, panorama shot, smile mode automatically identify. Voice camera features allow small gathering of friends, family photo to add more fun and warmth.



Camera


Retaining clip and moving

Tap the "Camera" icon to open the camera, switch to video mode. Tap"  ", ready video clips important moment in your life at any time.



Camera

Enjoy the colorful photos

Tap the "Gallery" icon to open the atlas . Feel free to browse photographs, memories moving moment. View a photo, tap"  " to enter the edit mode, you can crop photos, adjust color filter effects, such as increased landscaping operations.



Gallery

Send e-mail

Tap the "Email" icon.
After setting the e-mail account, you can send and receive messages via mobile phone, you can keep in touch with friends or clients at any times anytime and anywhere.



Email

Enjoy the wonderful music

Tap the "Music" icon.
You can play songs by Artists, Albums, Songs and other models.



Music


FM Radio


Insert the earphone plug into the socket. Tap the "FM Radio" icon, so you can Choose the radio frequency .



FM Radio

Change theme

Tap "  ", in the "Wallpaper" column, select a picture, then tap "Set wallpaper".



VOYAGER2 DG310

Le descriptif de ce guide peut contenir certaines différences avec celui de votre téléphone en fonction de la version du logiciel ou de votre opérateur.

Guide rapide

EN

FR