

5.6.6 Photo Editor

5.6.7 Music Player

Choose music player and enter mp3 play interface. Up/down left/right the four function key, act as stop/play/pause/select the last song, select the next song, press left soft key to enter play list, you can scroll to search songs. In playlist interface, press Play; play the currently chosen song.
Detail: View the detail of the song.
Add a ring: add the current song into the ring storage of profiles.
Update Song List: update song list.
Auto make list: Whether automatically updated the list when turn on the handset earphone.
Repeat: replay a song.
Random: the order is random when playing.
Stereo Background: the music will not stop as the menu exists.
Stereo sound output via Bluetooth: open the function, sound output via earphone.

Sound effects setting: can choose different music style after opening the balance.
Display lyric: can open or close when playing.
To play two record file in AB repeater.

5.6.8 AB repeater

Select the option to record. Press the left soft key to enter.
Play: play the currently chosen record.
Extra: add one new section after the currently chosen record.
Rename: rename the current record file.
Delete: delete the current record file.
Set: set record format.
Transmit: send the current record to the profiles or MMS, etc.

5.6.9 Record

The handset supports FM radio, choose FM radio menu to enter, press 'OK' key can start operation as following:
Channel list: can edit channel, name, shown on this list.
Manual input: directly input FM channel frequency.
Auto search and setting: auto search FM channel and auto update channel list.
Record: can record the radio message.
File list: enter Audio file folder.

5.6.10 FM Radio

Set can set play background and output to the handset loudspeaker.

5.6.11 FM Timer

Set the record time of FM radio.

5.7 TV

See 5.6.1

5.8 Email

See 5.2.4

5.9 Wireless LAN

The use of wireless LAN need to search for available networks and choose a suitable access point of network to set.
Enable / Disable wireless LAN: connect or disconnect current network, and choose a network.
Wireless network state: show the current network detail message when connected provider.
Access point setting: enter the menu, will show all access points list that defined, encryption mode, etc, for detail message please contact with your network service provider.
Create new connect point: create a new network access point.
Change Priority: set the current access point priority, while connecting network, the mobile will automatically select the high priority network.
Search: auto automatically select the high priority network, it will display the network list after finish searching, select a network, click option or press OK key.
Link: connect current network, click option or press OK key.
Define the access point: edit the access point message of the network, and can save as access point.
Detail message: view the detail message of the network, and can save Link management or disconnect the link.
Show the current linked wireless LAN message. Can view the network detail message.

5.10 Network Service

5.10.1 STK

The function provided by the network provider. If SIM card and network provider don't support the service, the function will not be used.

5.10.2 WAP

Your mobile phone support the service based on Wireless Application Protocol(WAP). You can visit the service that your network provider support. The service will make you obtain the messages of news, Weather Forecast and Flight etc.
Note: GPRS service needs network supports, you must opened and in the service area, it will can be used.
✓ From page-choose the front page, you can land in the front page. The front