

to mobile phone.

- **Chat:** can enter chat room to make chat with the sender.
- **Delete all:** delete all SMS in inbox.
- **Delete all messages of the same:** delete all messages of the contact in inbox.
- **Copy all:** copy all of the messages in SIM card to mobile phone, or copy all of the messages in mobile phone to SIM card.
- **Move all:** move all of the messages in SIM card to mobile phone, or move all of the messages in mobile phone to SIM card.
- **Use phone number:** pick up the phone number of the sender who sent the SMS, and you can dial it dial-up or save it in Phonebook.
- **Use URL:** link the bookmark URL in SMS.
- **Use the address of email:** use the address of email in message.

Outbox

Enter outbox to view the saved SMS; outbox divided into SIM card 1 and SIM card 2 outbox, they have the same operation method.

Draft box

Enter draft box to view the saved SMS that haven't sent.

Common phrases

Some commonly used phrases can be stored in Common Phrase to avoid the duplication of each enter while sending SMS. After it is finished, choose Edit or Delete.

SMS Setup

When using SMS function, you need to do the necessary settings at first.

- ✓ **Mode Setup:** choose a suitable mode for your SMS. Enter the corresponding names, SMS center number, period of validity and SMS format settings of all modes.
 - ✓ **Status Setup:** set whether to open the message report or return path.
 - ✓ **Capacity Inquiry:** view the storage space of SIM card or handset mailboxes.
 - ✓ **Storage Position:** choose your handset or SIM card.
- Set SMS center number: please contact with your network provider, to obtain the SMS center number.
- State report: if you set state report open, when the other side receive your SMS or because of some reason can't receive, the center will send back the state report, you can easily know if other side has received your message.
- Note: this function needs the support of network service provider.

5.2.2 MMS

Create
Create a new multimedia message. You need to fill the contents of receiver, copy, Encryption option, subject, cell.

Inbox
View received multimedia message (the same operation as SMS inbox).
Play: view the current content of the multimedia message.
Answer: to answer the current sender in the multimedia message.
Detail information: lookup the detail current information of the multimedia message.

Transmit: edit the relative information of the current multimedia message.

transmit: send current multimedia message.

Save picture: save current picture of MMS.

Save music: save current music of MMS.

Pickup number: pickup the number of sender.

Delete: delete current multimedia message.

Outbox

Outbox store the multimedia message when sent out not succeed (the same operation as SMS outbox).

transmit: send current multimedia message to other receiver.

play: play the current content of the multimedia message.

detail information: lookup the detail current information of the multimedia message.

delete: delete current message.

draft box: after editing, if you don't want to send, you can save it in draft box.

View: view current MMS.

send: send current multimedia message.

edit: can re-edit current multimedia message.

delete: delete current MMS.

delete all: delete all the parts in draft box.

Save as template: save current multimedia message as template.

use item: select the number in multimedia message to dial or save.

Draft box
Save the MMS selected to save when send it.

Template
There are preset MMS and MMS user creating in mobile phone.

Setting
Set multimedia message parameters about send and receive.

Edit setting: MMS network setting.

Send setting: set send network.

Receive setting: set receive network.

Filter: filter some messages.

Server setting: MMS network setting.

memory condition: lookup the situation of the space occupied.

5.2.3 Chat
Can set chat room and make chat with your good friends in SMS.

5.2.4 Email
Before using email, you must first set email account, enter email account, click the left soft key to select "option" to create a new account, enter a right email address, then choose the next in "option" to select the communication protocol POP3 or IMAP4, click the next, the data is GPRS, and click the next again in "option", to set receive server.

POP*** (such as POP 163.com), after finish setting, the next step is set the send server.