User Manual

2013

Android Version 4.2.1

CONTENTS

Basic terms

Root: ☒Super Android system is the administrator user account, which has the authority to control the whole system, and only have the privileges to the original system can be refreshed for the revision of the various systems;

APK: Android application types, with the cab and the Windows Mobile platform, like exe files, the user can be installed directly;

Eclari : The name of one of the Android platform, version, and the corresponding version number is 4.2.1, JK809 use this version;

Webkit: Core Android platform, browser, and now Apple's Safari, Google's Chrome and FireFox are using this kernel as a web page rendering mechanism;

GPhone: To use Google Android mobile phone operating system developed collectively, JK809, etc.;

ActiveSync: Push email solution to support Microsoft proprietary technology, pre-primary mailbox servers at Microsoft (Exchange server) to provide support, and now Google's Gmail also provided support

G-Sensor: Is the acceleration sensors for mobile phones can provide the direction of gravity sensors, which begin with the letter G represents the gravity, the latter Snesor meant to represent the sensor

Introduction

Introduction phone keys

Menu button: Click on the program display the corresponding menu item, the user can choose the corresponding sub-menu functions;
Home button: Click on the background into the current application will, and enter the main interface; Note that using this key will not really exit the application, the application will continue to run in the background;
Back button: Click to fall back to previous step of the operation of the interface;

Information Function

To sort the information by contacts, the conversational arrangement, user understanding of the history of the entire communication information, information sorted according to first contacts, including contact name for the first numbers, then letters (A-Z)

Send MMS
New information -"click ⊕ , add "function - " to select the desired additional content;
New information-click the menu button -add theme

Replacement SMS reminder tone

Access to the information interface - "click the menu button, select "Settings "function - Select "Notifications"function -Select " Ringtone"function;

View the sender information

Access to the information screen - "Select the message - " click [ ] - "click

, can view the sender information

Forwards

Access to the information screen - "Select the message - " Long press the Information, there shortcut keys - "select"Forward "function

View information details

Access to the information screen- "Select the message-" Long press the

Information, there shortcut keys -"select View details "function

Delete information session specific information on a particular
Access to the information screen - "Select the message - " Long press and
Information, there shortcut keys - "select "Delete "function

Contact Features

contacts groups, contacts and favorites feature;
Book description
By the first number, then sort the way English characters （A-Z）

Favorites Introduction
Included collection of contacts, and users often call the recent contact
information, part of the overall fabric Top of the contact information for the user
collection, lower often call into the system default contact information;

Contact Search

Into the contact interface - "click [🔍] button

Search supported by the first letter and the entire search string

Import contact information methods
using Bluetooth to achieve data synchronization
JK809 phone and the original binding, using Bluetooth to achieve
synchronization of contacts;

Call History Features

One by one to delete call records
Enter the call log interface - "Click the menu button –Select the delete
Function- " Choose the delete call records- click ok button

Contact information stored call records
Enter the call log screen - "Select the Save call log - " click- "select "Add to

Contacts "feature
Or directly into the call log entry, -click [ ] button -select "Add to Contacts
"feature

Paste the text / copy Features

Into the input field - "input string, long press and enter the region, there
shortcut keys - " select All " " cut All " ,"copy All","paste All"

E-mail Features

Configuring mail account

Enter the Program Group screen - "Select"Email"application -"Enter e-mail address and password

If the system automatically recognizes the mailbox information, will automatically configure; if the system does not recognize, will require users to type IMAP mailbox, or POP3, enter the appropriate configuration information.

Gmail For example:
E-mail Address: fulai89@gmail.com
Password:
Configure multiple email accounts
Enter the Program Group screen - "Select"Email"application -" Click on the menu button-select setting function -select "Add Account"feature

Delete email account
Enter the Program Group screen - "Select"Email"application - Click on the menu button-select setting function –select account - " select the "Remove Account"function

Email check frequency setting
Enter the Program Group screen - "Select"Email"application - Click on the menu button-select setting function –select account - " select I nbox check frequency "function

Bluetooth Function

Select "Settings" -" Select "Bluetooth"function

Wifi Features

Select "Settings"-"Select Wi-Fi"- select "Add NETWORK ", select the desired access APN

Flight mode Function

Select "Settings"-"Select More"-" choose "Airplane mode"function

Or select the phone, "Off"button - "select the" Airplane Mode "function

Black unlock

Select "Settings"-"Select " security "-" Select the " Screen lock"-Pattern

Restore to factory default

Select "Settings"-"Select"Backup&reset "-" select "Factory data reset"

Storage Settings

Select "Settings"-"Select"storage"

GPS Settings

Select "Settings"-"Select " location services"-" Check the "Enable GPS satellites "

English language switching phone

Select "Settings"- "Language & input "-" Select " Language ", select English or other

Language & input

Language
English (United States)

✓ Spell checker

Personal dictionary

KEYBOARD & INPUT METHODS

Default
English (US) - Android keyboard (AOSP)

Android keyboard (AOSP)
English (US)

✓ Google voice typing
Automatic

SPEECH

Voice Search

Text-to-speech output

Language

Català

Čeština

Dansk

Deutsch (Deutschland)

Deutsch (Liechtenstein)

Deutsch (Österreich)

Deutsch (Schweiz)

English (Australia)

English (Canada)

Input set

Select "Settings"- " Language & input "-click [button]

Android keyboard settings

Input languages
English (United States), English (United
Kingdom), Spanish, Russian, Vietnamese

GENERAL

Auto-capitalization ✓

Vibrate on keypress ✓

Sound on keypress

Popup on keypress ✓

Show settings key

Voice input key
Mic on main keyboard

TEXT CORRECTION

Auto correction

Replacement mobile phone input method

Select "Settings"- " Language & input "-Default

Language & input

Language
English (United States)

✓ Spell checker

Personal dictionary

Choose input method

English (US)
Android keyboard (AOSP)

Set up input methods

Google voice typing
Automatic

SPEECH

Voice Search

Text-to-speech output

Android phone data cable links

Select "Settings"-"Select"Developer options"-"Check"USB debugging "
Products installed on your computer drive, the link on the USB cable;

Developer options   ON

Take bug report

Desktop backup password
Desktop full backups aren't currently protected

Stay awake
Screen will never sleep while charging

Protect SD card
Apps must request permission to read
SD card

DEBUGGING

USB debugging ✓
Debug mode when USB is connected

Power menu bug reports
Include option in power menu for taking
a bug report

Allow mock locations
Allow mock locations

Select debug app
No debug application set

- 18 -

- 19 -

Introduce cross-screen display

Select "Settings"-""Display "-"Check"Auto- rotate screen, " according to the phone automatically change the direction of rotation

Browser Features

Visit the website

Browser - "Click url input area "-" Enter the URL of web browsing-click [C] button

Download Web page images or other objects

Browser - "browse the web, long press on the picture, there shortcut keys, choose "Save Image "function

Browser settings / search page

Browser - "browse the web -"click "menu button",-select settings / find on page

1. How to turn off the software running in the background too much

Download Advanced Task Manager Advanced Task Manager and select install, it can help you achieve, automatic end of the program services, to switch between programs, display memory information, exclusion list, an end of all widgets, fast uninstall program and other functions, To free up memory space, reducing the CPU's operation long pressure, increase speed, to extend the purpose of standby time.

Download:

http://m.91.com/soft/detail.aspx?platform=android&f_id=4001520

2. How to quickly set up Email

In the Android system, can automatically set the POP3 or IMAP e-mail most accounts, the e-mail application, directly enter the e-mail address and password, if not automatically fit in the mailbox, the mailbox will be required by user Server information. See details in front of the "E-mail Features"section.

3. How do I view the capacity of SD card case

Select the "Settings"-Select Storage -select "SD card and phone memory", will see the current SD card capacity information phone

4. How to save electricity JK809

First, reduce the screen brightness can be used in peacetime by reducing the brightness to reduce battery consumption, in the "Settings " in the "sound and display" found on "brightness", and then sliding scale in respect of the brightness can be set Android phones;
Close GPS global positioning, in the "Settings"and select" location services" -uncheck the following "Enable GPS satellite set" can be;
Usually if you do not use the Wi-Fi, Bluetooth headset can be improved by turning off these options to the standby time, turn off the WLAN search can save about 30% to 40% of standby time;
Usually close calls and text messages to remind vibration;

5. How JK809 lock screen, to prevent others from using

In the "Settings", select " Security "and then select "screen lock'"pattern", to set individual unlock pattern, to prevent strangers use or purpose of ensuring privacy of confidential documents.

6. Why does not the USB data cable links your computer

Confirmed in the phone's "Settings"-""Developer options"-" in the "USB debugging"functionality check; also installed the correct USB driver

7. How to install a program on a non-Android Market

Select "Settings"-"" Security ", the"unknown source "function check

8. In browsing the web or other applications, how to switch to other applications

If you need to open when browsing other applications, you can long press the Home key to achieving long task switch, long press return directly to the desktop (note that the system default task only last 6 months)

9. How to enter the silent mode quickly

In addition to continuing foreign long press the volume down key,and directly Into the status bar select the silent mode.

- 22 -

- 23 -

10. How to forward SMS / MMS

Long press and Information applications in the information content of an item in the list, until the pop-up shortcut menu, select "Forward" can be realized.

11. how to paste and copy text

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All","paste All"

12. download and install the application installation path can be set to SD card

Platform reason, the application can only be installed in the phone flash memory

13. In the phone program group is installed too many applications, how to solve

In the desktop space – sliding the application to another application – click the application to open New Folder

14. Contacts are sorted, can change

Sort of way platform, the first number, then letters, then the Chinese way of sorting; the user can not set their own sort

15. Contacts whether to support the group

In the contacts interface-select group

16. contacts and SMS storage capacity limits the number of

Platform reason, contacts and SMS storage for no clear limit value, depending on the size of the current mobile phone memory space

17. How to set the SD card, personalized ring tones

In the SD card, are established "ringtones" (ringtones) "alarms" (alarm tone) "notifications" (SMS notification tone), the ring tones into a different folder, the phone can be automatically identified.

18. How to sync the phone contacts to the original JK809

using Bluetooth the way, the two cellphone, sync contacts;

19. How to use the JK809 access Wifi (WLAN)

Wifi signal at the scene to ensure that the premise of the specific see "Wifi function "

20. How to Find Contact

Into the contact interface, select the "Search"menu, you can search for contacts, you can use the first letter of query letters;

21. how to download applications for the JK809

1) Visit Google Market http://www.android.com/market/; need to pay to download some software;
2) third-party sites, access to applications, such sites are:

http://www.waptw.com/
http://android.sj.91.com/list/rjyxhj.shtml
......

More downloaded software will be installed in the SD card and some software may vary depending on operating system version, network access nodes, size or other reasons can not be used.

22. What are commonly used android forum

http://www.waptw.com/
http://sj.91.com/
http://www.android123.com/
http://www.android86.com.cn/
http://www.androidin.net/bbs/index.php
http://bbs.zhiqi.com.cn/forum-33-1.html

23. How do I delete the downloaded software

"Settings" - ""Manage app"-"Select the application to be deleted

24. How to view mobile phone version information

"Settings" - "" About phone "mobile phone version information can be obtained, including the Android version, Linux version, software version, hardware version, etc.

25. How do I copy SIM card contact information

Into the Contacts application, click the menu button, select "Import Contacts", then you can see the SIM card contacts, if only to import one, you can click an item. If all the import needs to long press the menu key, select Import to import all.

26. why the message has a different time and date display

Message displayed on the principle that the display of the day time and date have shown that non-day

27.JK809 whether to support the Java

Platform reason, JK809 does not support Java, if you need to install third-party Java applications, you need to install the Java runtime environment JK809.