LED WATCH INSTRUCTION MANUAL

电池：手表使用 2 粒 CR2032 纽扣电池，当灯变暗时，请更换电池。

功能：1） 计时 12 小时 24 小时制　　3） 年

2） 星期和日期　　4） PM 指示（只在 12 小时制）

重复按 A 键进入以下模式:

时钟图标，12 小时制或 24 小时制均显示。

太阳图标，指示日期和星期。

美金图标，指示年,寓意赚钱一年多过一年。

马爹利图标，指示 PM. 马爹利通常是在晚上喝。

读时间:

按 A 键.时钟图标灯亮（如果马爹利图标亮时，表示下午），此时显示时间。.表有四个纵列，左边的两列代表【时】,右边两列代表【分】，如下图

读日期:

按 A 键，直到太阳图标灯亮，此时显示星期和日期。最左边的列表示星期，最右边两列表示日期。如下图

读年：按 A 键，直到美金图标灯亮，此时显示年，从左边到右边看。如下图

设置手表

手表按以下次序设置，手表内置星期自动调整功能，因此在设置日期时需先设置年和月。

设置时间

按 A 键，灯亮，灯亮，然后按 B 键开始设置时间

- 现在小时灯闪烁.按 A 键调整小时，然后按 B 键确定。
- 现在分钟灯闪烁，按 A 键调整分钟，然后按 B 键确定。
- 最后选择 12 小时制或 24 小时制，按 A 键选择，然后按 B 键确定。

设置 年和月

按 A 键 ，然后按 B 键开始设置年和月

- 现在年灯闪烁.按 A 键调整年，然后按 B 键确定。
- 现在月份灯闪烁. （01=Jan，02=Feb，etc），按 A 键调整月，然后按 B 键确定。

设置日期

按 A 键 ，灯亮，然后按 B 键开始设置日期

- 现在日期灯闪烁，按 A 键调整日期，然后按 B 键确定。

同时星期灯根据选择的日期自动调整，1=星期日，2=星期 1，3=星期 2，…

设置完以上步骤，手表将自动计算出该月有多少天，并且自动确定该日是星期几。



时间
8：47PM

日期
星期日 26 号

年
2008

Power：The watch works with two CR2032 batteries.Change the batteries when the luminousity is too weak.

Function： 1）1Time in 12hr or 24hr mode　　3）Year

2）Day and date　　4）PM indicator(only in 12hr mode)

Press the A button repeatedly to move through the watch modes.

Clock Icon.Represents the time in either 12hr or 24hr mode.

Sun Icon . Represents the day/date.

Dollar Icon. Represents the year. Making more and more money after year.

Martini Icon. Represent PM . Drinking is usually done at night.

Read the watch：Press A button.Clock Icon lights(when Martini Icon aslo ltghts,it means PM) The watch has four lines led: the left two lines indicates hours, and the right lines indicates minutes.

Read day/date：Press A button，when Sun Icon lights the left line indicates day,and the right two lines indicates date.

Read year：Press A button，when Dollar Icon lights, then the watch indicates year

How to set the watch

The watch should be set in order blow.The watch has a built in calendar to set weekday automatically,so it is required to set the year/month before the day/date. Set the time 设置时间

Press A button, Icon lights，then press B button to begin setting the time

- The hours will be flashing.Press A button to change hours,then press B button to accept.
- Now the minutes will flashing.Press A button to change minutes,then press B button to accept.
- Lastly ,select 12hr or 24hr mode.Press A button to change and press B button to accept.

Set the year/month

Press A button, Icon lights,then press B button to begin setting the year/month.

- Now the year LED will be flashing.press A button to change and press B button to accept..
- Now the moth LED will be flashing. （01=Jan，02=Feb，etc）Press A button to change and press B button to accept..

Set date

Press A button, icon lights,then press B button to begin set the date.

- Now the watch two right lines will be flashing,.Press A button to change and press B button to accept.

Meanwhile the left line LED will change automatically.(1=Sunday,2=Monday,etc).

Once this is set the watch will know how many days are in the month and what day of the week it should be.



Time
8：47PM



Date
Sunday 26th



Yeat
2008