power off your phone. Mobile phone will interfere with heart pacemaker, hearing aid and other medical equipments. Use mobile phone near heart pacemaker will make it dysfunction. In order to interfere with heart pacemaker, Advanced Medical Technology Association suggest you that mobile phone must keep distance with heart pacemaker at least 6"(15cm).

Interfere
All wireless phones may be susceptible to interference, which could affect performance.

Accessory and battery
Please use the battery and charger that this company specified, Please don't connect incompatible products.

Right Use
As the product file show, phone only can be used at the right position. If no necessary , please don't touch the antenna area.

Emergency Call
Make sure the handset is powered on and within the service area. Input emergency number, then press dial key to tell your position . please don't stop the call without permission.

3 Before Using

3.1 The functions and descriptions of every part

3.1.1 the handset appearance



3.1.2 Keyboard Introduction

1. hang up key: end call or reject incoming call; long press the key to power on/off; in other case, press the key normally return to standby status.
2. up /down side key: adjust volume , in submenu, it is the roll option key to scroll up

and down.
3. camera Key: in standby status, press the key to enter camera mode directly.

3.1.3 Side Key Introduction

Your mobile side key has easy using function, in a time, if user don't do any operations, the mobile will auto shut off the background light. While the background light off, you can press left side key to light the background.
While calling, press left side key can adjust the volume of headphone.
When have incoming call , press side key can increase the ring volume, press the side lower key can change to mute mode.
In music player interface , play or pause, press side key can adjust the volume of music play, while the button adjusting, the volume icon on the player face will changed together.

3.1.4 Icon

antennal icon, the signal strength, the more line, the stronger the signal.
capacity of power, the less of the bar, shows the electricity shortage
new message
clock alarm
ring style
vibration style
vibrate then ring
vibrate while ring
keypad lock
earphone
call forward
GPRS link
wireless network

3.1.5 Install and Disassemble SIM card and Battery

You must first insert an effective SIM card before using your handset, and only the battery is charged full, can you use your phone.
Note: SIM card must put to the place where children can't reach.
Carefully insert or remove SIM card, avoid bending or hurting the SIM card and the connect point.

Replace the battery:
Hold the on/off key , about tow seconds the phone will powered off.
1. Push out the back cover of handset downwards .
2. Hold the bottom of battery and push upwards, take the battery out.

Install SIM card:
Insert SIM card into SIM-A or SIM-B slot, the bevel of card aimed to the bevel of slot, the mental surface of card faced to handset.