FEATURES:

Manual

Front Light

DC Input

Rear Light

USB

The USB link line

O

* Ultra-bright 3 Watt CREE LED spotlight (cool white light), SOS signal light

- W Ultra-bright 3 Watt CREE LED spotlight (blue light)
- ※ Beam distance around 100M

With USB output (5V), provides recharging power for cell phone or MP3

* Battery charging indicator

Equipped with 4000mAh Li-ion battery, battery service time around
Equipped with 4000mAh Li-ion battery. 10 hours for spotlight (white and blue light), 20 for SOS signal light.

※ Recharge by AC/DC battery charger

PRODUCT ACCESSORIES:

- ※ AC/DC charger
- * Tripod
- USB charging cord

OPERATION INSTRUCTIONS:

- ※ Disconnect from charger.
- The on/off power switch is located in the front of the spotlight.
- ※ Front spotlight (white) → SOS signal light → Rear spotlight (blue) → Power off

DC 5V Adapter

RECHARGING THE BATTERY:

- # Before recharging the battery, turn the function switch to off position.
- * Before using the spotlight for the first time, charge the battery for 10 continuous hours using the AC battery charger.

White Light SOS Blue Light 4 OFF

ON/OFF Switch

Tripod

SPECIFICATION:

% LFD

3 Watt CREE LED (cool white and blue light)

***** Battery

4000mAh Li-ion battery

※ AC/DA Charger Input: 100-240VAC 50/60Hz Output: DC 5V500mA

*** USB output**

5V 500mA

▲ WARNING:

- * Close supervision is necessary when any appliance is used by or near children. Do not allow to be used as a toy.
- ※ To protect against risk of electrical shock, do not put unit or charger in water or other liquid.
- % Do not use excessive force on the product as it may cause permanent damage to the unit.
- Always keep the lantern fully charged when not in use. Fully recharged, the battery can be stored for up to 3 months without recharging. Storage of the lantern for more than 6 months without recharging will damage the battery.
- ※ It is important to recharge the lantern as soon as possible after each usage.
- Do not shine directly into eyes.



To ensure the batterys life, please charge the battery every 3 months when the latern is not be used for a long time. When the light is dark during using, that means the energy power will be exhausted. In order to protect the battery, please stop using, and charge it in time (please charge before the led bulb is dark fully, otherwise it would damage the battery).