

## INSTRUCTIONS FOR USE

1. Insert 3 AA Batteries into the compartment on the bottom of your Violight UV Cell Phone Sanitizer. Please use alkaline or lithium batteries for best results.
2. To open your sanitizer, simply lift the silver cover off of the black base.
3. Inside your Violight UV Cell Phone Sanitizer there is an accessory basket for use with smaller items such as small MP3 players, Bluetooth headsets and earbuds. If you are using one of these smaller devices, place the item in the basket and then place the basket into the sanitizing chamber. Use the top section of the basket to neatly wrap your earbud cord, making sure the earbuds hang inside the basket so they are exposed to the UV light.



accessory basket

4. Place your cell phone or large MP3 player directly into the UV chamber, or place the accessory basket (see step 3) into the sanitizing chamber. Make sure the device or basket is firmly seated so the small button at the bottom of the sanitizing chamber is fully depressed.
5. Replace the silver cover. The small window on the front of the cover will pulsate blue, letting you know the sanitizer is eliminating up to 99% of germs.
6. In 4 minutes the blue light will turn off, indicating that your device is fully sanitized. Remove the silver cover and take out your device.



UV light window showing that unit is operating



cover

base

Your VIOLight UV Cell Phone Sanitizer has a built in safety feature that will not allow operation unless:

- a) your device or accessory basket is placed in the unit, firmly resting on the small black button at the bottom of the sanitizing chamber
- b) the silver cover is properly seated on the black base

## CLEANING & CARE OF YOUR VIOLIGHT

Use a moist cloth or sponge to clean the exterior surfaces of your UV sanitizer as needed.

A dry cloth can be used to gently clean the inside of the unit.

NEVER immerse in water, or place under running water for any reason.

## TROUBLESHOOTING

If for any reason your unit fails to work after placing your electronic device or accessory basket in the sanitizing chamber and covering the unit, please check the following:

**Are the batteries inserted correctly?**

**Are the batteries new?**

**If rechargeable, are they fully charged?**

**Is the cover on securely?**

**Is your device or the accessory basket seated properly, so the black button on the floor of the sanitizing chamber is fully depressed?**