
A6

Getting Started Manual



Started to use your phone:

Power on: Press and hold the power key button for 3 seconds.

Power off: Press and hold the power key buttom for 3 seconds, select 'power off' in the menu option.



Menu Key: Select to show the available menu in current screen.

Home Key: Return to home screen. To view recent application, press and hold the home key.

Back Key: Return to previous screen.

Volume Key: Adjust the volume of the ringtone.

Reset Key: Long press for 10 seconds to shut down the phone when phone is abnormal.

Camera key: Long press to enter camera in home screen.

SIM1: Should be inserted into a standard SIM card.

SIM2µ SD: Should be inserted into a Micro SIM card and a micro SD card.

⚠ Note: Please power off the phone before plugging in or pulling out the SIM card and micro SD card. And then make sure the covers of SIM1 and SIM2 are perfectly plugged.

Install the SIM 1 card

1. Pull out the cover of SIM1 as shown in figure 1:




Figure 1

2. Insert the standard SIM card into the slot and then plug the SIM 1 cover as shown in figure 2:



Figure 2



Install the SIM 2/micro SD card

1. Pull out the cover of SIM2/micro SD card as shown in figure 3:



Figure 3

2. Insert a micro SD card and a micro SIM card into the corresponding slot and then plug the cover as shown in figure 4:



Figure 4

T-Flash card:

1. Connect USB, turn on USB storage.

Automatically pop up USB connected interface after connecting USB, and then click Turn on USB storage to use the T-Flash as USB storage.



Using of touch screen:

- Single Click: To select an icon. For example, click dial to open the keypad which will be displayed on the screen.
- Double Click: To zoom-in or zoom-out. For example, to zoom-in or out of a photo, click twice when viewing a photo or browsing on the internet.
- Hold: Click and hold the screen, icon or input box to get more operation options.
- 1) Long-Time Click a picture in the gallery list interface, the status bar prompts to select a picture, you select to share or delete.
- 2) Long-Time Click the blanks of home screen to add home screen shortcut.
- 3) Long-Time Click the blanks of home screen wallpaper sources can be selected.

Home screen:

You can use various functions of the phone screen through the touch screen. Click the icons to open the applications. View all applications by clicking an application tab.Intotal, there are 5 home screens in the phone, when you slide to the left or to the right this will move the screen from one to another.

To set wallpaper, tap and hold at blank area on any of the screens. You can return to the home screen by pressing the Back key in any screen.

Status Bar



Create shortcuts and widgets

Click the main screen and then Pop-up list of application. Hold and click the application icon which you want to add a shortcut. Drag the application icon to the area you want to place, release the hand that add. To add widgets the same way as add a shortcut or enter the widget menu to add widgets. As shown the following figure:



Delete the shortcuts and widgets

To delete an object, tap and hold the object, then drag it towards the bottom of the screen X Remove . When the object turns red let go of it and the selected object will be deleted.



Lock the screen

Lock the phone in order to avoid useless operation and to save the battery by press the power key. The phone will automatically lock when it is not being used for some time.

Set wallpaper

Hold and click main screen pop-up box and you select wallpaper source. Click and enter WALLPAPERS gallery to pick image \ live wallpaper\video wallpaper can be set. As shown the following figure:



Unlock the phone

Press power key to enter the unlock interface and then slide unlock. As shown the following figure:





Message board

Drag the status bar of any screen can open the message board. Click the icon in the upper right corner to bring up the settings interface and various parameters setting interface. As shown the following figure:



Manage applications

Install applications: Found in the file manager to install the software (. APK), then follow the prompts step by step installation Uninstall application: Enter Settings->Apps->Downloaded, then will be able manage and remove installed applications.



Recently used applications

Press and hold the home key, the screen will display a window which shows your recently used applications. Click the icon to open the application.



Extend the standby time:

Some functions may use up more power, which eventually shorten the standby time.

- Close all the wireless connection when not in use Bluetooth, WI-FI or GPS.
- Reduce the brightness and shorten the screen timeout to save battery, or press power key to shut down the screen when the phone is not in use.
- Close any automatically synchronized applications such as Email, calendar, contacts and other.
- Some applications which are downloaded could also shorten the standby time.