


LED Magic Rainbow Lamp User's Manual

I. Function overview

1. Vase lamp
2. Overall switching color decoration lamp and sleep lamp;
split switching color decoration lamp and sleep lamp
3. Handheld flashlight lamp
4. Battery charging function
5. Power-failure auto-light color decoration lamp

II. Product illustration



- ① Handheld section touch function zone ② DC outlet
③ Handheld section ④ Lampstand

III. Instructions for operation

1. Take your product out of the package and charge it immediately for at least 15 minutes to activate it.
2. Put the product horizontally on desktop. After plugging power adaptor, DC plug is as shown in ② to charge the product.
3. When you press any part of the product downward, lampstand will give off color light and automatically switch between different colors when you pressing for the first time; when pressing for the second time, blue sleep lamp will light up at the lampstand section; press it again to turn it off.

1. Touching the touch zone (as shown in Figure ③) for the first time when the handheld section is on the lampstand, the flashlight section will give off color light and automatically switch between; when touching it for the second time, blue sleep lamp will light up; touch it again to turn it off; When off position at lampstand is connected with external power supply, handheld section will automatically light up and switch between colors.
2. When handheld section is separated from the lampstand, touch the touch zone ① as shown in diagram for the first time and the flashlight lamp in the handheld section will light up; touch it again and it will switch to color decoration lamp; touch it again and the blue sleep will light up; touch it one more time to switch it off.
3. This product has charging function. When handheld section is placed on lampstand connecting with external power supply, it will automatically charge the built-in battery in the handheld section; in normal charging, the handheld section will give off faint red light; when charging is complete, the handheld section will give off faint green light.

IV. Basic parameters:

1. Material: polycarbonate
2. Capacity of built-in battery in the handheld section: 210mah
3. Charging: around 2H
4. Discharging time: 25-3.5H, depending on specific light

V. Points for attention

1. Please charge this product before use.
2. When the product stays unused for a prolonged time, please don't touch the touch zone to open the handheld section. Otherwise, it may cause damage to battery due to prolonged storage.
3. To avoid unnecessary accident, never put the product in fire or water.
4. To avoid burning circuit, never use higher than 5.5V power supply to charge the product.
5. When the product is to stay unused for prolonged time, please keep it at a dry location. To avoid battery damage, it is better to charge the product every three months.