## 9 inch TFT-LCD MONITOR



#### CAUTION

Changes or modifications not expressly approved by the party resonsible for compliance could void the users authority to operate the equipment.

## Content

Caution	2
Name And Function Of Each Parts	4
Power And Mode Selection	6
Remote Controller	6
Picture control	7
System	8
Clock	9
Connection Diagram	10
Installation	11
Specifications	12

## Caution

Please read and observe all warnings and instructions in this owner's manual and those marked on the unit . Retain this booklet for future reference.

There are two kinds of alarm symbols as follows:



The lightening fash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of dangerous voltage within the product, s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to people.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance(servicing) instructions in the literature accompanying the product.

#### A WARNING



Installation of all TV monitors must be out of the driver's field of sight.



Do not mount the product where it will obstruct the deployment of the airbag or in an area where it would affect the vehicular control. Also be careful to avoid mounting the product where it can become hazardous during sudden stops or in the event of an accident.



Do not try and service these products yourself. Seek only a qualified service center or factory sevice center.




Use extra caution with any liquids in your car. If you or your child spill any liquid on these products, pull your vehicle to the roadside and turn the key off to disconnect



Be careful not to drop or apply under pressure to the front panel of your video monitor. If the screen cracks due to misuse, your warranty will be void!







Be careful not to overload your cigarette lighter plug by adding more than one device at a time.



Use only a damp cloth to clean the screen and use only purified water on the cloth ,wring out all excess water prior to wiping the screen. Do not use any cleaners or chemicals to clean the screen. In most cases a dry cloth will do!

#### Caution

## A CAUTION



Quality installations are best performed by qualified and certified installers.



Watching the monitor for an extended period of time without the engine running may deplete the vehicle's battery charge.



Don't touch the unit there is a flash of lightning. It may receive an electric shock.



This product is designed for operation with a 12 Volt DC, negative ground vehicle .lt is not suitable for operation under other conditions or voltages.




Do not cover or stop up heater ducts or vents .lt may be the origin of a fire or receives an electric




Do not bring magnetic devices such as credit card or magnetic card near the magnets.

# Name And Function of Each Parts



# Name And Function of Each Parts



#### \*Caution

Do not bring magnetic devices such as credit card or magnetic card near the monitor.

## **Power And Mode Selection**


#### POWER ON/OFF

Select desired **POWER ON/OFF** by pressing the  $\circlearrowleft$  button on the unit or on the remote control.




#### Mode Setting

Select the desired mode by pressing the MENU button on the unit or on the remote control.





## **Name And Function of Each Parts**




#### Picture Control

#### CONTRAST/BRIGHT/COLOR/TINT

Select the one of **CONTRAST/BRIGHT/COLORT/TINT** and change the picture condition as your taste.


1.Bring up the on-screen function menu by pressing the MENU button on the unit or the TFT MENU button on the remote control.



2.Select the desired menu by pressing the MENU button on the unit or the TFT MENU button on the remote control. Highlight the desired function to change Contrast, Bright, Color, Tint etc.



3. Control the desired screen conditions by pressing the **ch-** or **ch+** buttons on the unit or the **addition-/+** buttons on the remote control.



4.RESET

## Şystem

#### • SYSTEM

Select the SYSTEM as yours laste

1.Bring up the on-screen function menu by pressing the menu button on the unit or the TFT-MENU button on the remote control.



2. Select the mode ,AV,ROTATION,BLUE, menu by pressing the menu button on the unit or the TFT menu button on the remote control.



3. Select the mode AV . Rotation , Blue mode by pressing the ch- or ch+ buttons on the unit or the Addition -/+ buttons on the remote control.

## Clock

#### · CLOCK

1.Bring up the on-screen function menu by pressing the menu button on the unit or the TFT menu button on the remote control.




Select the clock menu by pressing the menu button on the unit or the TFT menu button on the remote control.



3. Control the Audio quality by pressing the ch- or ch+ buttons on the unit or the Addition-/+ buttons on the remote control.



# Connection Diagram.



# \*How to connect the DOOR TRIGGER wire

- 1.connect the power cable and press the DOOR button on the unit.
- 2.Open the door and connect the +/- trigger wire with door trigger on the car, if lamp is on , please connect this wire with car door trigger.

# Installation


1. Open the color box and check the contents.








2. Match the position installation bracket and installation plate with screw A.



3. Tighten the unit with the supplied screw B.



# **Specifications**

Power	DC 12V
Screen Format	16:9
Resolution	800(H)*RGB*480(V)
Color System	NTSC / PAL Auto Selection
Vinput	1 EA
A/V Output	1EA
Dimension	323(w)x292(D)x62(H)mm/12.7``(W)x11.5``(D)x2.4``(H)
\	

Note: This equipment has been tested and has been found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in some case the user will be required to correct the interference at his own expense.