


3D Smart Projector

Quick Start Guide




1. In the Box



Projector



Remote Control



AV Cable



5.1CH Cable



User Guide



Certification




AAA Batteries



HDMI Cable




Wi-Fi Antenna




Adapter

2. Product Overview




3. Connect Projector



Note:

1. The VGA Cable is optional.
2. Micro SD card is inserted with metal mouth down.

4. Remote Illustration



	Mute		Power Switch						
	Home page		VGA input		HDMI input		AV input		
	OSD menu		Volume -		Volume +		Return		
	Left		Right		Up		Down		Enter
	Cursor		Video online		Application				
	Prev		Play / Pause		Next				
	Scaler		Image Mode		Rotate		Keystone		Keystone
	2D		2D To 3D		SBSH		TNB		

Note:

- a. SBSH: Side-by-side. TNB: Top and bottom.
- b. and can only work when playing 3D formats video.
- c. The remote uses 2 AAA batteries.

5. Turn on Projector

A. Power connect



B. Press the power button on the projector



C. Adjust the screen

a. Press keystone (⏏) or (⏏) on the remote to finish keystone correction.


With Keystone Correction





Without Keystone Correction




b. Turn the focus ring on the right side of projector to sharpen the image.



6. Main Menu




7. Wi-Fi Set Up




Choose the Wi-Fi switch to Scanning Wi-Fi.
Click the Wi-Fi you want to connect and type in the password with screen keyboard.

Note: Please make sure that WI-FI Antenna has been connected to projector.



8. DLNA


With DLNA, video, photo and music can be transmitted between devices built-in Android system. To play DLNA, application to contact phone and the projector needs to be installed into your phones. For example, MirageDLNA application.



Note: Please make sure that Projector and your mobile phone on the same WI-FI when play DLNA.

9. Use it as Computer

Surfing Internet




Playing Games



Downloading APPs



Editing Files



10. Watch 3D


10.1 Use 3D glasses (Optional device)

Switch on:



Press the power key on 3D glass, after the indicator blinking once, then the 3D glass is ready to use.

Switch off:


Press the power key for 2 seconds, then switch off the 3D glasses. It will power off after blinking 3 times. By the way, the glasses will automatically power off if doesn't receive any 3D signals in 5 minutes.



10.2 3D Play

Please select 3D video, press  or  on the remote to change 3D video format.

a. For Side-By-Side format video, please select .

b. For Top-and-Bottom format video, please select .