


# Manual



## Wireless Speaker with Power Bank



### Partial View

- 1.USB interface, Power Output/Input
- 2.Power Bank /Flashlight switch
- 3.Pocket lamp bulb
- 4.Previous/Volume -  
Short press to play previous song,  
long press for volume down.
- 5.Mic
- 6.Pause/Play; answer/hang up the call
- 7.Indicator:  
play: blue  
Charging: red
- 8.Power ON/OFF;Mode

### 9.9.Next Song/Volume +

Short press to play next song, long  
press for volume up.

### 10.LINE IN

### 11.TF CARD

### 12.Hang rope position

### 13.Non-slip silicone

## Usage

### 1.The wireless connection

Long press the power button, the blue  
light will flashing. the device ready to pair.

Play via Computer

Activate Computer's wireless, if the  
computer does not built-in BT, plug on  
a BT adapter, also need extra BT driver.  
Turn speaker to pairing mode(Blue light  
flashing quickly)-Search " JL BT" -  
Pairing- Connect and Play.

Play via Mode phone

Activate Mode phone's wireless-  
Search Find' JL BT' -pairing-Connect  
and play

## **2. The TF card play**

Playing songs in MP3 format which saved in TF card.

## **3. The LINE IN function**

Connection device 3.5 MM audio interface, easy to complete with PC/ IPOD/PHONE/MP3 / MP4R perfect docking (short press the "M" key to switch to the LINE - IN mode).

## **4. The power bank**

Short press the Power Bank switch, the power indicator will light up, each indicator represents twenty-five percent of the total quantity of electricity.

## **5.LED Flashlight function**

Continuous press the Power Bank switch twice to ON/OFF

## **Parameter**

Wireless version: V3.0

Wireless transmission power:

CLASS2-4dBm

Wireless working frequency: 2.4GHz

Charging voltage: DC5V/500mA-1A

Charging time: 5hour

Power Bank output: 5V-1A

Working voltage : DC 3.7V

Battery capacity: 4000MA

Speaker parameter: 4Ω5W X2 φ40MM

THD :  $\leq 0.1\%$

Signal to Noise Ratio:  $\geq 90$  db

Music/talking time: 8H

Wireless range: 10-20m

## **Troubleshooting**

1.Hands-free call is only available at wireless connected status; Still the phone call could be interfered with high frequency electromagnetism.

People should try not to use this product under high frequency environment.

2.Wireless is a bidirectional transmitting protocol; transmitting distance is highly related to audio player. Compatible BT players are recommended.

3.When wireless transmitting devices cannot be connected, please delete the rest BT receiving devices name on the list. Re-activate "JL BT", re-searching and re-pairing.

4.The sound performance could also be affected when BT transmitting devices is under poor signal environment, or under low battery capacity.